


# ASSEMBLY INSTRUCTION

00-220P/W BEDROOM

00-220P/W MIRROR

LIST OF HARDWARE			QTY
	SCREWS	#8*1-1/4"L	10PCS

1. Carefully place Mirror on the Dresser and line up center line.
2. Attach the two wooden Mirror supports to the Mirror and Dresser using the wood screws provided.

